

<u>How the test is carried out</u>	<u>What is unacceptable</u>	<u>Notes</u>
<p><u>DOORS, BOOT AND LUGGAGE SPACE</u></p> <p>Physically check that all doors, hinged emergency doors and boot lids:</p> <ul style="list-style-type: none"> • Open and remain open • Close and remain closed, secured by latches etc. 	<p>Does not open and/or remain open</p> <p>Will not close and/ or remain closed</p> <p>Catches fail to activate or hold</p>	<p>Some vehicles may have doors or openings that are deliberately put out of use.</p> <p>Providing that the remaining doors or openings meet with the standards for the type of vehicle, this will be acceptable.</p>
<p><u>BOOT AND LUGGAGE SPACE</u></p> <p>Visually check that the boot or other luggage space:-</p> <ul style="list-style-type: none"> • Is free from contamination by dirt, litter, tools, etc. • Has sufficient space available for luggage • Has a method of securing luggage or goods in the event of a collision 	<ul style="list-style-type: none"> • Contamination • Insufficient space • No method of securing items 	<p>Hackney and Private Hire Vehicles must have at least 12.5 cubic feet of luggage space</p> <p>Special Event Vehicles will not need to provide luggage space</p>